

**Abbott Rental & Party Store**  
**502 Union Street, Littleton, NH 03561**  
**603-444-6557      www.abbottrental.com**

## **COTTON CANDY MACHINE**

### **Instructions**

Be sure equipment is connected to properly grounded 120 volt power supply with 15 amp circuit. Plug directly into a dedicated outlet. Extension cords may create a safety hazard and reduce performance. Be sure outlet accepts 3-prong grounded plug. DO NOT use a 3-prong to 2-prong adapter.

#### **\*OPERATION:**

1. Press the MOTOR switch to the ON position.
2. Fill the spinner head with the desired amount of sugar floss. Never fill the head past the bottom level of the filler spout.
3. Press the HEAT switch to the ON position.
4. Turn the HEAT CONTROL knob to heat setting HIGH.
5. Once floss starts to flow out of the head, reduce the HEAT CONTROL to the green range as indicated on the METER (too high of a setting will cause cutting of the floss and potentially clog the head screen).
6. When the amount of floss that is produced starts to slow, add more sugar. DO NOT adjust the HEAT CONTROL knob setting, keep in green range.
7. NOTE: The typical operating setting on the heat control is in the green range. This will vary, however, due to fluctuations in the environment.

#### **\*SHUTTING DOWN:**

1. Press HEAT switch to the OFF position.
2. Wait 3-5 minutes for the spinner head to cool down.
3. Press the MOTOR switch to the OFF position.

In Case of a Malfunction immediately shut off the MOTOR and HEAT switches and correct the problem.

**Do Not Clean Equipment, Return As Is**

## TROUBLESHOOTING

1. Bad Vibration: Check to make sure there are no sugar lumps in the spinning head
2. Motor does not operate, but heater is operating: Motor protection has tripped off. Wait one minute and restart.
3. Floss is being formed with clumps of sugar or floss is forming, but being cut: HEAT CONTROL is set at too high a setting.
4. Head is full of sugar but no floss comes out: Check the settings of heat and HEAT switch and HEAT CONTROL.

### Additional Info:

One cone will hold approximately 1 oz of spun sugar, and this machine will produce anywhere from 100—200 cones per hour, based on practice.

### Included in your rental:

Machine Base  
Plastic Bowl  
Mesh Webbing  
8 Clips

*You will be charged if any of these item are not returned.*

**Do Not Clean Equipment, Return As Is**